



ORIGINAL INSTRUCTIONS

Instruction Manual
Reed Auto switch – Band mounting
Series D-A33(A) / D-A34(A) / D-A44(A)



The intended use of the auto switch is to detect and control the position of an actuator using magnetic detection.

1 Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of “Caution,” “Warning” or “Danger.” They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)^{*)}, and other safety regulations.
^{*)} ISO 4414: Pneumatic fluid power - General rules relating to systems.
ISO 4413: Hydraulic fluid power - General rules relating to systems.
IEC 60204-1: Safety of machinery - Electrical equipment of machines. (Part 1: General requirements)
ISO 10218-1: Manipulating industrial robots -Safety. etc.
• Refer to product catalogue, Operation Manual and Handling Precautions for SMC Products for additional information.
• Keep this manual in a safe place for future reference.

	Caution	Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
	Warning	Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.
	Danger	Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

Warning

- **Always ensure compliance with relevant safety laws and standards.**
- All work must be carried out in a safe manner by a qualified person in compliance with applicable national regulations.
- This product is class A equipment intended for use in an industrial environment. There may be potential difficulties in ensuring electromagnetic compatibility in other environments due to conducted or radiated disturbances.

Warning

- Special products (-****) might have specifications different from those shown in the Specifications section. Contact SMC for specific drawings.


2 Specifications

2.1 D-A33(A) / D-A34(A) / D-A44(A) specifications


Model	D-A33(A)	D-A34(A) / D-A44(A)		
Wiring style	2 wire			
Application	PLC	Relay, PLC		
Load voltage (maximum)	24 VDC	24 VDC	100 VAC	200 VAC
Load current	5 to 50 mA	5 to 50 mA	5 to 25 mA	5 to 12.5 mA
Internal voltage drop (max.)	2.4 V	2.4 V max. (< 20 mA) 3.5 V max. (< 50 mA)		
Contact protection circuit	None	Built in		
Operation time	1.2 ms			
Indicator lamp	LED is ON (Red) when switch is ON			
Impact proof	300 m/s ²			
Insulation resistance	50 MΩ or more at 500 VDC mega			
Proof voltage	1500 VAC for 1 minute (between case and lead wire)			
Ambient temperature	-10 to 60°C			
Protection structure	IP63 to IEC 60529 (JISC 0920)			

3 Names of Individual parts

D-A33(A) / D-A34(A)



D-A44(A)



Note! The mounting band Hook is not applicable to models D-A33A / D-A34A and D-A44A.

4 Installation

4.1 Installation

Warning

- **Do not install the product unless the safety instructions have been read and understood.**

4.2 Design and Selection

- 1) Confirm the specifications.
Read the specifications carefully and use the product correctly. The product may be damaged or malfunction if it is used outside of the specification range.
- 2) Take precautions when multiple actuators are used close together.
When multiple auto switch actuators are used in close proximity, magnetic field interference may cause the switches to malfunction. Maintain a minimum actuator separation of 40 mm.
- 3) Pay attention to the length of time that a switch is ON at an intermediate stroke position.
When an auto switch is placed at an intermediate position of the stroke and a load is driven at the time the piston passes, the auto switch will operate, but if the speed is too great the operating time will be short and the load may not operate correctly.

The maximum detectable piston speed is:

$$V \text{ (mm/s)} = \frac{\text{Auto switch operating range (mm)}}{\text{Load operating time (ms)}} \times 1000$$

4 Installation (continued)


- 4) Keep wiring as short as possible
As the wire length to a load is increased, the inrush current at switch ON becomes greater, which may shorten the product life (the switch will stay constantly ON).
Use a contact protection box when the wire length is 5 m or longer.
- 5) Pay attention to the internal voltage drop of the switch.
 - 1) Switches with an indicator light
 - If auto switches are connected in series, take note that there will be a large volt drop because of internal resistance in the LED's (refer to internal voltage drop in the auto switch specifications). [The voltage drop will be “n” times larger when “n” auto switches are connected].
Even though an auto switch operates normally, the load may not operate.
 - In the same way, when operating below a specified voltage, although the auto switch may operate normally, the load may not operate. Therefore, the formula below should be satisfied after confirming the minimum operating voltage of the load.

Supply voltage	--	Internal volt drop of switch	>	Minimum operating voltage of load
----------------	----	------------------------------	---	-----------------------------------

 - 2) If the internal resistance of an LED causes a problem, select a switch without an indicator light.
- 6) Do not use a load that generates a surge voltage.
If driving a load such as a relay that generates a surge voltage, use a contact protection box (CD-P11 / CD-P12).
- 7) Caution for use in an interlock circuit
When an auto switch is used for an interlock signal requiring high reliability, devise a double interlock system by providing a mechanical protection function, or by using another switch (sensor) together with the auto switch.
- 8) Perform periodical maintenance and confirm proper operation.
Ensure sufficient clearance for maintenance activities when designing an application.

4.3 Mounting and Adjustment

- 1) Do not drop or bump the product.
Do not drop, bump or apply excessive impact (300 m/s² or more) while handling. Although the body of the switch may not appear damaged, the inside of the switch may be damaged and cause a malfunction.
- 2) Do not carry an actuator by the auto switch lead wires.
This may not only cause broken lead wires, but it may cause internal elements of the switch to be damaged by the stress.
- 3) Mount switches using the correct tightening torque.
If an auto switch is tightened beyond the tightening torque range, the mounting screw, mounting bracket or switch may be damaged.
On the other hand, tightening below the tightening torque range may allow the switch to slip out of position.
- 4) Mount the auto switch at the centre of the operating range.
Adjust the auto switch mounting position so that the piston stops at the centre of the operating range (range in which the switch is ON). The mounting position shown in the catalogue indicates the optimum position at the end of stroke. If mounted at the end of the operating range (around the borderline of ON and OFF) operation may be unstable.
- 5) The auto switch ON and OFF position operates with a hysteresis. If the hysteresis causes a problem, please consult with SMC.



4 Installation (continued)


4.4 Mounting using a mounting bracket

Each actuator has a specified mounting bracket type. Mounting depends on the actuator type and tube I.D. Please refer to the actuator catalogue.
When an auto switch is mounted for the first time, ensure that the actuator is the type with a magnet built-in, and prepare a mounting bracket corresponding to the actuator.


4.5 Mounting the auto switch (D-A33, D-A34 and D-A44)

- 1) Loosen the auto switch mounting screws at both sides to pull down the hook.
- 2) Place the auto switch mounting band on the cylinder tube and set it at the required mounting position, then hook the band.
- 3) Gently tighten the auto switch mounting screw.
- 4) Set the whole assembly at the detection position by sliding, then fix the auto switch by tightening the mounting screw. Recommended tightening torque: 2 to 3 N.m.
- 5) The detection position can be changed following from step 3 above.

D-A33 / D-A34




D-A44



4.6 Mounting the auto switch (D-A33A, D-A34A and D-A44A)

- 1) Tighten the auto switch mounting screws on the auto switch body at both sides.
- 2) Place the auto switch mounting band on the cylinder tube and set it at the required mounting position.
Put the mounting section of the auto switch between the gap in the mounting band, then adjust the position of the mounting holes of the switch to those of the mounting band.
- 3) Gently thread the mounting screws through the bracket mounting hole into the threaded part of the band fitting.
- 4) After confirming the detecting position tighten the auto switch mounting screw to secure the auto switch.
Recommended tightening torque: 2 to 3 N.m.
- 5) The detection position can be changed following from step 3 above.

D-A33A / D-A34A / D-A44A



4 Installation (continued)

4.7 Band mounting



- It is important to set the mounting band perpendicular to the cylinder tube.




4.8 Wiring


- Avoid repeatedly bending or stressing lead wires.
Broken lead wires can result from wiring layouts which repeatedly apply bending stress or stretching force to the lead wires.
- Be sure to connect the load before power is applied.
If the power is turned ON when an auto switch is not connected to a load, the switch will be instantly damaged due to excess current.
- Confirm proper insulation of wiring.
Check that there is no faulty wiring insulation (contact with other circuits, ground fault, improper insulation between terminals, etc.)
Damage may occur due to excess current flow into a switch.
- Do not route wiring with power lines or high voltage lines.
Avoid parallel wiring or wiring in the same conduit with these lines.
Control circuits containing auto switches may malfunction due to noise.
- Do not allow short circuit of loads.
If power is turned ON with a load in a short circuit condition, the switch will be instantly damaged due to excess current flow.
- Avoid incorrect wiring
An auto switch with indicator light has polarity. The terminal no.1 is (+), and the terminal no.2 is (-).
If connections are reversed, the switch will operate, however, the LED will not turn ON. Also note that a current greater than that specified will damage the LED and it will no longer operate.

4.8.1 Wiring diagram

D-A33 / D-A33A



D-A34 / D-A44 / D-A34A / D-A44A



4 Installation (continued)

4.9 Environment



- Do not use in an environment where oil, corrosive gases, chemicals, salt water or steam are present.
- Do not install in a location subject to vibration or impact in excess of the product specifications.
- Do not mount in a location exposed to radiant heat that would result in temperatures in excess of the product specification.
- Do not use in an area where a magnetic field is generated.
Auto switches can malfunction or magnets inside actuators can become demagnetized.
- Do not use in an environment where the auto switch will be continually exposed to water.
- Do not use in an environment with temperature cycles.
- Avoid accumulation of iron waste or close contact with magnetic substances. A large amount of accumulated iron waste such as machining chips or spatter may cause the auto switch to malfunction.

5 How to Order

Refer to the catalogue or operation manual on the SMC website (URL: [https:// www.smcworld.com](https://www.smcworld.com)) for How to order information.

6 Outline dimensions

Refer to the catalogue or operation manual on the SMC website (URL: [https:// www.smcworld.com](https://www.smcworld.com)) for outline dimensions.

7 Maintenance


7.1 General Maintenance



- Not following proper maintenance procedures could cause the product to malfunction and lead to equipment damage.
- If handled improperly, compressed air can be dangerous.
- Maintenance of pneumatic systems should be performed only by qualified personnel.
- Before performing maintenance, turn off the power supply and be sure to cut off the supply pressure. Confirm that the air is released to atmosphere.
- After installation and maintenance, apply operating pressure and power to the equipment and perform appropriate functional and leakage tests to make sure the equipment is installed correctly.
- If any electrical connections are disturbed during maintenance, ensure they are reconnected correctly and safety checks are carried out as required to ensure continued compliance with applicable national regulations.
- Do not make any modification to the product.
- Do not disassemble the product, unless required by installation or maintenance instructions.
- Perform the following maintenance periodically in order to prevent possible danger due to unexpected auto switch malfunction.
 - Securely tighten switch mounting screws. If screws become loose or the mounting position is dislocated, re-tighten them after readjusting the mounting position.
 - Confirm that there is no damage to lead wires. To prevent faulty insulation, replace switches or repair lead wires, etc., if damage is discovered.

8 Troubleshooting

When detection failure occurs check the switch according to the chart



- (A) = Auto switch failure
(B) = Replace the actuator. Detectable magnetic field inadequate (or no magnet).
(C) = Correct the wiring, replace the load or replace the auto switch after correcting the wiring.
(D) = After checking the operating environment, replace the auto switch.
(E) = Replace the auto switch after correcting the wiring.

9 Limitations of Use

9.1 Limited warranty and Disclaimer/Compliance Requirements

Refer to Handling Precautions for SMC Products.

10 Product disposal

This product should not be disposed of as municipal waste. Check your local regulations and guidelines to dispose of this product correctly, in order to reduce the impact on human health and the environment.

11 Contacts

Refer to www.smcworld.com or www.smc.eu for your local distributor/importer.

SMC Corporation

URL : [http:// www.smcworld.com](http://www.smcworld.com) (Global) [http:// www.smc.eu](http://www.smc.eu) (Europe)
SMC Corporation, Akihabara UDX15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101 0021
Specifications are subject to change without prior notice from the manufacturer.
© 2023 SMC Corporation All Rights Reserved.
Template DKP50047-F-085M